

# User Manual

---

## FFS-10000



[www.star-technologies.co.in](http://www.star-technologies.co.in)



# CATALOG

<b>1. PREFACE</b> .....	<b>3</b>
MAINCONTENT .....	3
SECURITY WARING .....	3
MAINTENANCE NOTES .....	4
TRANSPORTATION AND STORAGE.....	4
SPECIFICATION.....	4
POWER SUPPLY AND CHARGING.....	7
MAINSCREEN .....	9
BRIGHTNESS SETTING .....	11
VOLUME SETTING .....	11
<b>2. QUICK REFERENCE GUIDE</b> .....	<b>12</b>
<b>3. SPLICE</b> .....	<b>14</b>
SPLICE MODE.....	14
AUTO START .....	15
CAMERA .....	17
HISTORY .....	20
<b>4. HEAT</b> .....	<b>23</b>
HEATMODE .....	23
AUTOSTART .....	25
<b>5. MAINTENANCE</b> .....	<b>25</b>
BRIGHTNESS ADJUSTMENT .....	25
DAILY CLEANING WORK .....	27
ELECTRODES REPLACEMENT .....	29
<b>6. SYSTEM</b> .....	<b>32</b>
SYSTEM INFORMATION .....	32
RESOURCE DOWNLOAD .....	32
LANGUAGE .....	32
DATE TIME .....	33
STARUP PASSWORD.....	33
POWER SAVING MODE .....	34
AUTO SHUT DOWN .....	34
LCD DIRECTION .....	34
FACTORY RESET .....	35

**7. ERROR AND SOLUTION .....35**

- "ERRORS AND SOLUTIONS" ..... 36
- "MOTOROUTOFLIMIT" ..... 36
- "FIBERDIRTY" ..... 36
- "FACEANGLE TOO LARGE" ..... 37
- "END FACE ERROR" ..... 37
- "FIBER ANGLE TOO LARGE" ..... 37
- "DUST BURN" ..... 37

**8. CONNECT THE PC SOFTWARE .....38**

- INSTALLATION AND CONNECTION ..... 38
- UPGRADING THEFIRMWAREOFTHESPLICER ..... 40

**9. TIPS.....40**

- HOW TO IMPROVE THE SPLICING QUALITY ..... 41
- WHEN TO USE AUTO SPLICE MODE (X6 ) ..... 41

# 1. PREFACE

## MAINCONTENT

Thanks for choosing [Star FFS-10000 Fast Fusion Splicer](#).

This manual particularly introduces the function features,operation skills, maintenance notes and precautions of [Star FFS-10000 Fast Fusion Splicer](#)

Two models are introduced in this manual:

[FFS-10000](#) full functional optic fiber fusion splicer (hereafter called FFS-10000) [FFS Series](#) high-performance optic fiber fusion splicer

Notes:

In this manual,the FFS-10000 pictures are used for description (including the cover) by default.



**Important !!**

**Be sure to read all this manual carefully before use.**

For more information,please contact local distributor or visit website:  
[www.star-technologies.co.in](http://www.star-technologies.co.in)

## SECURITY WARING

This machine is only used for splicing the silica glass fiber. It cannot be used for other purpose.As the splicer is the high precision machine, please be cautious to carry and operate, and follow the below safety regulations:

- Do not use the machine in an explosive hazardous situation.
- Do not touch the electrodes when the machines power-on!
- Never disassemble the machine by yourself.Any

problem, please contact the authorized maintenance center to repair it.

- Do not expose the machine in fire,thunder,rain,and humid environment.
- Do not stack the battery and adapter up each other when charging, otherwise it will cause the fire.

## MAINTENANCE NOTES

- Do not clean V-groove and electrodes with hard and sharp objects.
- Do not clean any parts with acetone, gas or other cleaning chemicals.
- Please conform to more maintenance instructions in the subsequent chapters of this manual.

## TRANSPORTATION AND STORAGE

- To avoid the emergence of condensation,the machine should be kept at least 1hour to accommodate environment from coldness to warmth.
- If it is not used for a long time,the machine should be cleaned, packed well and kept in a dry place.
- If it is not used for a long time,the machine should be charged every three months.
- The machine should be put in the carrying case to avoid damage and dirty when carried.
- Keep the splicer away from the direct sunlight, extremely high temperature or relative humidity over than 95%.

## SPECIFICATION


Size & Weight	D190×W140×H150(MM); <b>FFS-10000</b> :1.8kg(2.2kg with battery)
Fiber alignment	<b>FFS-10000</b> :6 motors core alignment
Fiber type	SM(ITU-T G.652), MM(ITU-T G.651), DS(ITU-T G.653), NZ/NZDS(ITU-T G.655), BI(ITU-T G.657)

Splice mode	Single fiber
Fiber diameter	Cladding diameter 80 ~ 150um, coating 100 ~ 1000um
Cleave length	250um cladding diameter 8 ~ 16mm, over 250um cladding diameter 16mm
Minimum splice length	20mm
Splicing programs	Max.100
Splicing cycle time secs.[Auto]	<b>FFS-10000</b> :6 secs.[SM Fast] program, 10 program
Heating programs	Max.30
Heating cycle time	Adjustable, 12 secs. typical
Splice protector	10 ~ 60mm
Splice image capture	Max.300
Splice data storage	Max.20000
Splice loss	SM:0.02dB, MM:0.01dB, DS:0.04dB, NZ/NZDS:0.04dB, BI:0.02dB
Return loss	>>60dB
Loss estimation	Provided
Operation condition	Altitude 0~5000m, Humidity 0~95%, Temperature -20~+50℃, Wind velocity up to 15m/s
Storage condition	Humidity 0 ~ 95%, Temperature -40 ~ +80℃ (Battery -20 ~ +40℃)
Tension	1.96 ~ 2.25N
Fiber view	Two cameras observation, 4.1 inch high-light color screen
Fiber magnification	560x for X or Y single axis view,180x for both X&Y dual axis view
Port	High speed USB
Electrode life	5000 arc discharges
Power supply	AC100-240V, 50/60Hz

Battery module

**FFS-10000**:8400mAh High capacity battery, more than 350 times splicing and heating

## STRUCTURE



## POWER SUPPLY AND CHARGING

- Install/Remove the battery:



Insert the [Battery Pack](#) into the machine in the direction as indicated by the red arrow.



Press the [Battery Release Button](#) to remove the battery as indicated by the red circle.



- Power supply with AC Adapter:



1. Remove the **Battery** from the machine;
2. Insert the **AC adapter/Battery Charger** into the machine(same place as the battery);
3. Insert **AC Power Cable** into the AC Adapter/Battery Charger and start getting energized.

- Battery charging:



1. Connect the AC Adapter with the Battery by **DC Power Cable**;
2. Insert **AC Power Cable** into the AC adapter, and then start getting energized.





**Important!!**

**Do not stack the battery and adapter up each other when charging.**

## **MAINSCREEN**

Insert the Battery Pack or AC Adapter/Battery Charger and






Press the power key  until it turns green, then the splicer starts work and self-checking. After finish, the splicer enters into the **Main screen** and shows “Ready”.



Now open the wind-protector and start the fusion work.






## BRIGHTNESS SETTING


Follow these steps:

- On the [work interface](#),press UP key ,the brightness menu come out;
- Press UP key  and DOWN key  to adjust the brightness. After finish,press the  to save(or press back key  to give up).




## VOLUME SETTING

Follow these steps:

- On the [work interface](#),press DOWN key ,the VOLUME menu come out;
- Press UP key  and DOWN key  to adjust the volume. After finish,press the  to save(or press back key  to give up).



## 2. QUICK REFERENCE GUIDE



Open the wind-protector and put the fiber into the V-groove

Close the wind-protector and start the splicing process


Having finished Splicing, take the fibers away.

Move the protection sleeves to cover the splicing point.

Place the fiber into the heater. Start the heat process.

Completed.


Place the end of fiber between the V-groove edge and the center of electrodes. **Notice: Do not touch the cleaved fiber end face against any surface.**




While maintaining a slight tension on the fiber end, do not twist or flex the fiber. Just lower the fiber into the heater as the arrow pointing direction. The oven hood will be closed and start heating automatically.

### 3. SPLICE

#### SPLICE MODE


When the splice mode is not matched with the fiber type, click the **Menu**  key on the work interface, then enter to the **Splice mode**, select and enable the splice mode which matched with the fiber type.



When the fiber type is uncertain, **AUTO** mode is suggested, but the splicing speed will be slower.

(Pay attention: **AUTO** mode is only available for **FFS-10000**)

## AUTO START



**Auto start** includes two options:

ON	Close the wind-protect under <a href="#">work interface</a> , start to splice automatically.
OFF	Close the wind-protect under <a href="#">work interface</a> , no response.

## PAUSE 1, PAUSE 2,

**Pause1** includes the following options:

ON	When starts to splice under the <a href="#">work interface</a> , the splicer will be paused for confirmation after finishing cleaning & discharging operation.
OFF	When start to splice under the <a href="#">work interface</a> , the splicer will keep operating after finishing cleaning & discharging operation.





**Pause2** includes the following options:

ON	When starts to splice under the <b>work interface</b> , The splicer will be paused for confirmation after finishing the second time alignment.
OFF	When start to splice under the <b>work interface</b> , The splicer will keep operating after finishing the second time alignment.

## CAMERA

This option is for setting up the display mode of X/Y view during the fiber splicing process.

**FFS-10000 Fast Fusion Splicer** has two cameras, the display images from these two cameras called **X-view** and **Y-view**.




Camera interface shows several steps while a fiber splicing process:

Gapset	Push the fibers into view.
Clean	ARC to clean the fiber.
Align	Adjust fibers to align approximately.
Align again	Adjust fibers to align accurately.
ARC	ARC to splice the fibers.
Estimate	Estimate the splicing loss.
Complete	Splicing finished,wait for tension test.

For each step, Camera options are available as below:

X	Show the X-view only
Y	Show the Y-view only.
X/Y	Show both X-view and Y-view.

## SKIP ERROR



**Skip error** interface lists various errors that may be detected in a fiber splicing process:


Fiber end face error	Fiber is not found,face uneven or dust
End face Angle too large	Cutting angle is too large.
Fiber angle Too large	The fibers of V-grooves are not in the same level (There may be dust on the V-grooves or fiber surface.)
Dust burn	It finds dust burning when discharging and splicing(There is dust on the fiber surface or the fiber end face.)
Loss too large	The estimated loss is large after splice (This Splicing may be not eligible.)


For each error,these **Skip error** options are available:

ON	Warn and pause to confirm when detects Corresponding error.
OFF	Skip and keep operating when detects Corresponding error.

## **ELECTRODE MENU**

Electrodes are the consumable parts. According to different materials and manufacturing processes,each new electrode has its life time(discharge times). **Electrode menu** is used for automatically recording the lifetime of new electrodes.



Replace notice	When the electrodes' discharging time reach to the setting point of this option, it will remind you to replace new electrodes on the <a href="#">work interface</a> .
Replace warning	When the electrodes' discharging time reach to the setting point of this option, it will remind you to replace new electrodes on the <a href="#">work interface</a> in a obvious way.
Clear current counter	It records the current ARC counter. After changing new electrodes,select this option,push  to clear the record to restart recording the ARC times of new electrodes.



**Important !!**


**Using inferior electrodes will lead to the splicer's abnormal working or even breakdown. Please contact with the Jetfiber agent to purchase original electrodes.**

## HISTORY

[History](#) interface will automatically record the specification data of each splicing operation and the estimate loss in order to take reference inquires about the statistics.


History includes [View history](#) and [Clear history](#)



Press  under the [View History](#), you can check all the splice data records. All there records are placed according to the splice date. The latest record was arranged on top.

A screenshot of a software interface showing a green header bar with the word "History" and a pause icon. Below the header is a table with seven rows of splice data records. The first row is highlighted in yellow. The table has three columns: a sequence number, a date and time, and a value.


Sequence	Date and Time	Value
0007.	2017-01-09 12:24	0.01
0006.	2017-01-07 15:44	0.01
0005.	2017-01-07 15:30	0.01
0004.	2017-01-05 17:12	0.01
0003.	2017-01-05 17:12	0.01
0002.	2017-01-05 17:11	0.00
0001.	2017-01-05 17:10	0.01


Press  under the [Clear History](#).

All splice data can be cleared.

## 4. HEAT

### HEATMODE


Press the key  in the [work interface](#) when the heating mode is not matched with the protection sleeve which is currently being used. Then enter into the [Heat mode](#) interface, choose a heat mode that is matched with the protection sleeve.





The [\[40mmstd.\]](#) and [\[60mmstd.\]](#) mode are designed for working above 0°C which are respectively used for heating the common 0~40mm and 40~60mm protection sleeves. When the heat is not sufficient due to the fairly thick protection sleeve or the low temperature, please follow these steps until improved:

1. Switch from [\[XXmm STD.\]](#) mode to the corresponding [\[XXmm PLUS\]](#) mode;

- Heat the 40mm protection sleeve under the [60mmstd.] or [60mmplus] mode;




- When the heat is not sufficient even under the [60mmplus] mode, select [New=>] item, press  key to create a new heat mode, set up the heating Time to 25s, return and select this option to start this mode;
- When the heat is still not sufficient even finish the above steps, select the new heat mode created above, press  key to enter into the Mode edit interface, prolong the Heat time an extra 5s and test whether successful;
- Repeat the step 4 until getting the most suitable heating time that can heat sufficiently under the current environment.



---

## AUTOSTART

[Auto start](#) includes the follow options:

ON	Put the fiber in the heater.The splicer will start to heat automatically once the heater cover is closed.
OFF	Put the fiber in the heater.The splicer will start to heat only when press the  key.


## 5. MAINTENANCE

Since the splicer is the high precision machine, it should be cleaned and maintained regularly while being used in order to guarantee the optimum performance.

### BRIGHTNESS ADJUSTMENT

Be affected by the external environment, the image brightness of optical imaging system is unqualified because of dirty camera interface. The system of fusion splicer will be brightness adjusted automatically, this caused the splicing time slower. Please adjust the brightness of fusion splicer.

- Power on the fusion splicer, Pres  go to [Maintenance](#)
- Press [Brightness](#)




---


## DAILY CLEANING WORK

There are mainly two parts need daily cleaning: **V-groove** and **Microscope Lens**:


1. When clean the **V-groove**, follow these steps:
  - Wipe the bottom of the V-groove with a small cotton swab dipped by alcohol;



- Suck the remaining alcohol in the V-groove with a dry cotton swab;
- Jab out the dirt in the V-groove with the end part of a cleaved fiber.



2. When clean the [microscope lens](#), follow these steps:
  - Wipe the surface of the microscope lens with a small cotton swab dipped by alcohol



- Suck the remaining alcohol on the surface of the Microscope lens with a dry cotton swab.

---

## ELECTRODES REPLACEMENT


When ARC times surpass the electrodes' lifetime, the discharging will be unstable, and splicing loss goes larger.


So, suggest users to clean the electrodes after every 500 times splicing.

When the splicer warns users of replacing electrodes, please change the electrodes as required to guarantee the splicer's performance.


Please operate as the following steps:

- Shut down the splicer, unfasten the screws to remove the electrodes holder, replace the old electrodes with the new ones, then install the electrodes holder on the splicer;





- Power on the splicer, press the  key, and then enter into the Maintenance menu;


- Run Electrode Stabilize;



- Run ARC Adjust




- Enter into the Splice / Electrode menu interface, select Clear current counter item, push  key to zero the ARC counter in order to restart recording the ARC times of the new electrodes.



## 6. SYSTEM

### SYSTEM INFORMATION

System information interface presents all the basic information of the current system of the splicer, including the temperature inside the wind-protector detected by temperature sensor.



### RESOURCE DOWNLOAD

Resource download interface provides FFS-10000 fast fusion splicer upgrade tools, PC software and other resources to download the link two-dimensional code. If you want to upgrade the fusion splicer, welding data export, remote control assistance and other operations, please enter the interface scan QR code, download the corresponding resources.

### LANGUAGE

Language interface are available for the specific sales area. All the



languages under this menu can be selected.

## DATE TIME

Date time interface is for setting date and time. The exact date and time would be shown on functions like splice history and image storage, etc. Correct date and time can make your information more accurate.

The power supply on the mainboard makes sure time run precisely when the machine is off. Normally, the power supply can work several years. If the system time stops working when the machine is off, please contact the authorized Jetfiber service center to change a new power supply.

## STARUP PASSWORD


Startup password function used to set power-on password setting .



Startup password switch settings :

OFF	Turn off startup password function, it can be used directly after boot up.
ON	Turn on startup password function, it can't be used till enter password. Initial password:0000 , do remember the password after turn on startup password function.

Select the password Settings to set up password:



## POWER SAVING MODE

The splicer can run at power saving mode when idling time. These options are available:

OFF	When this function is off, the machine won't go into power saving mode automatically anytime.
(Number)	The machine will go into power saving mode automatically when there is no operation during the setting times. Unit: second.

## AUTO SHUT DOWN

The splicer can shut down automatically while idling.

These options are available:

OFF	When this function is off, the machine won't shut down automatically at anytime.
(Number)	The machine will shut down automatically when there is no operation during the setting times. Unit: second.

## LCD DIRECTION

When the LCD Screen direction is up or down, the image on the display will change accordingly at the same time.

These options are available:

Auto	The image on the display will turn up or down automatically.
Front	The image on the display always shows forward.


Back	The display image always shows backward.
------	--

### FACTORY RESET

**Factory Reset** is used for recovering factory parameters while splicer can not work, which caused by splicing parameter, heating parameter or system information in disorder. After this action, all the manual models which been added would be cleared away.


## 7. ERROR and SOLUTION

ERROR is for alarming the wrong operation currently happened.




This part would show some common errors and the corresponding solutions

## “ERRORS AND SOLUTIONS”

ERROR	REASON	SOLUTION
“FIBER PLACED ERROR ”	<ul style="list-style-type: none"> <li>● The fiber is placed in the incorrect position.</li> <li>● There is some dust in the V-groove.</li> </ul>	<ul style="list-style-type: none"> <li>● Press the  and reposition the fiber, and make sure that the end-face of the fiber is between the edge of the V-groove and the middle of the two electrodes.</li> <li>● Clean the V-groove.</li> </ul>

## “MOTOROUTOFLIMIT”

ERROR	REASON	SOLUTION
“Motor out of limit”	<ul style="list-style-type: none"> <li>● The fiber is placed in the incorrect position.</li> <li>● There is some dust in the V-groove.</li> </ul>	<ul style="list-style-type: none"> <li>● Press the  and reposition the fiber, and make sure that the end-face of the fiber is between the edge of the V-groove and the middle of the two electrodes.</li> <li>● Clean the V-groove.</li> </ul>

## “FIBERDIRTY”

ERROR	REASON	SOLUTION
“Fiber dirty”	<ul style="list-style-type: none"> <li>● There is some dust on the surface of the fibers.</li> </ul>	<ul style="list-style-type: none"> <li>● Strip the fibers again, clean up them with dustless cloth dipped by alcohol, then cleave the fiber again.</li> </ul>

## "FACEANGLE TOO LARGE"

ERROR	REASON	SOLUTION
"Face angle too large"	<ul style="list-style-type: none"> <li>● The fiber is not well- cleaved.</li> </ul>	<ul style="list-style-type: none"> <li>● Strip the fibers again, clean up them with dustless cloth dipped by alcohol,then cleave the fiber again.</li> </ul>

## "END FACE ERROR"


ERROR	REASON	SOLUTION
"End face error"	<ul style="list-style-type: none"> <li>● The fiber end-face is fragmentized and uneven.</li> </ul>	<ul style="list-style-type: none"> <li>● Strip the fibers again, clean up them with dustless cloth dipped by alcohol, then cleave the fiber again.</li> </ul>

## "FIBER ANGLE TOO LARGE"

ERROR	REASON	SOLUTION
"Fiber angle too large"	<ul style="list-style-type: none"> <li>● There is some dust on the surface of the fibers.</li> <li>● There is some dust in the V-groove.</li> </ul>	<ul style="list-style-type: none"> <li>● Strip the fibers again, clean up them with dustless cloth dipped by alcohol,then cleave the fiber again.</li> <li>● Clean the V-groove.</li> </ul>

## "DUST BURN"

ERROR	REASON	SOLUTION
"Dust burn"	<ul style="list-style-type: none"> <li>● There is some dust on the surface of the fibers.</li> <li>● There is some dust in the V-groove</li> </ul>	<ul style="list-style-type: none"> <li>● Strip the fibers again, clean up them with dustless cloth dipped by alcohol,then cleave the fiber again.</li> <li>● Clean the V-groove.Clean the V-groove.</li> </ul>



When shows  
 “Connected” means  
 machine is connected  
 successfully

“History” and “Firmware” includes 2  
 big functions of the software.

### EXPORT STORED FUSIN SPLICE RECORDS

With the assistance of Fusion Splicer software, it is much easier to export the fusion splicer records under the menu “History”. Follow these steps:

- Power on the machine, press menu button, enter into “More” ,under “Splice” menu then choose “History” and “ Export History” . Follow the steps shown on the display: Create export files till it shows “Complete”
- Start Fusion splicer software, choose “History” ,click “Receive” button;
- Click the “save “ button on the Fusion Splicer software to save the fusion splice records on the PC.
- This file can be opened with Microsoft Excel and other compatible softwares.


---

## UPGRADING THE FIRMWARE OF THE SPLICER

Enter into the “[System /System information](#)” interface to check the firmware version of the splicer. Users can get the newest update file from COMWAY distributor, and then upgrade the firmware of the splicer as the below steps:

Follow these steps:

- Please refer to the previous chapter how to connect the machine and PC with USB cable. Start [Fusion Splicer](#) software, click “[Firmware](#)” button;




- Click “[Select Files...](#)” button, you can find the upgrade file, then “[Open](#)”
- When it shows “[Complete](#)”, power off the machine and restart.
- Press menu button, enter into “[System Info](#)” to check whether the system is upgraded to the newest version.

## 9. TIPS

## HOW TO IMPROVE THE SPLICING QUALITY

If the users follow the tips when use the splicer,good splicing quality can be achieved,even zero splicing loss. Here list some important tips:

- Preparatory work before splicing:Daily Maintenance Press the menu key,enter into the daily maintenance interface,finish the maintenance operation according to the tips;



- Choosing the corresponding **Splice mode** according to the fiber type (instead of Fast splice mode).E.g.,if the fiber type is SM,then choose SM G652 splice mode (instead of **SM Fast** splice mode);

**Tips: When don't know the fiber type, choose Auto to splice the first time. Once learn the exact fiber type, then switch to the right splice mode. (Auto only can be used on FFS-10000)**

- Cleaning the V-groove every500 times discharging and splicing.

## WHEN TO USE AUTO SPLICE MODE ( FFS-10000 )



---

The biggest difference between **AUTO** splice mode another splice mode is that the splicer will identify the fiber type under the **AUTO** splice mode and then automatically choose the **standard splice mode** to splice.

e.g.The splicer will select **SMG652** splice mode when it identify out the fibers are both SM type.So the splicing time under the **AUTO** splice mode will be longer than the **standard splice mode**.

**Tips:Choose Auto splice mode when the fiber type is unknown ,and the splicer will identify the fiber type automatically .After confirming the fiber type,then switch to the corresponding splice mode in order to improve the efficiency of the following splicing work.**

## **STAR FFS-10000 MANUAL**

**VERSION: 1.0**

The models and specifications could be amended at anytime without prior notice.